

# Network Service Module Hardware Reference



AT-AR040  
AT-AR041  
AT-AR042  
AT-AR048

Network Service Module Hardware Reference  
Document Number C613-03022-00 REV J.

Copyright © 1999-2007 Allied Telesis, Inc. All rights reserved. No part of this publication may be reproduced without prior written permission from Allied Telesis.

Allied Telesis, Inc. reserves the right to make changes in specifications and other information contained in this document without prior written notice. The information provided herein is subject to change without notice. In no event shall Allied Telesis, Inc. be liable for any incidental, special, indirect, or consequential damages whatsoever, including but not limited to lost profits, arising out of or related to this manual or the information contained herein, even if Allied Telesis, Inc. has been advised of, known, or should have known, the possibility of such damages.

All company names, logos, and product designs that are trademarks or registered trademarks are the property of their respective owners.

# Contents

---

Devices Covered By This Document .....	4
Hardware Overview .....	4
Compatible Base Units For NSMs .....	4
Operating Environment And Regulatory Standards .....	5
AT-AR040 NSM .....	6
AT-AR041 and AT-AR042 NSMs .....	7
Basic Rate ISDN Interfaces .....	7
ISDN S/T Interface Cables .....	9
Testing a BRI NSM .....	9
AT-AR048 NSM .....	12
DS3 Interface .....	12
DS3 Interface Cables .....	12
Testing a DS3 NSM .....	13
LEDs and What They Mean .....	14
AT-AR040 NSM .....	14
AT-AR041 and AR042 NSMs .....	14
AT-AR048 NSM .....	15
Switch and Router LEDs Related to NSMs .....	15
PIC LEDs .....	16
Hot Swapping .....	18
Hot Swapping the AR040 NSM with PICs .....	18
Behaviour of Hot Swapped Interfaces .....	18
Troubleshooting .....	20
For More Information .....	21
Document Sets .....	21
Contacting Us .....	21

## Devices Covered By This Document

This Hardware Reference includes information on the following devices:

- AT-AR040
- AT-AR041
- AT-AR042
- AT-AR048

The latest Hardware Reference can be found at [www.alliedtelesis.co.uk/site/products/](http://www.alliedtelesis.co.uk/site/products/).

## Hardware Overview

NSMs are expansion options for those switch and router models that have an NSM bay. NSMs slot into a base-unit switch or router and either directly provide additional WAN interfaces, or provide multiple slots where PICs (with WAN interfaces) can be added.

### Compatible Base Units For NSMs


Table 1 on page 4 lists NSM-ready products and indicates which NSM model can be used in each.

Table 1: Compatibility of NSMs models

Family	Model(s)	AR040	AR041 & AR042	AR048 <sup>1</sup>
Rapier	Rapier 8/8 (MT & SC)	✓	✓	
	Rapier 16F-FX (MT-RJ & SC)	✓	✓	
	Rapier 16Fi-FX (MT-RJ & SC)	✓	✓	
	Rapier 24	✓	✓	
Rapier <i>i</i>	Rapier 24 <i>i</i>	✓	✓	✓
AR800 Modular Switching Router	AR816F-FX (MT-RJ & SC)	✓	✓	
	AR824	✓	✓	
AR Routers	AR740	✓	✓	
	AR745	✓	✓	

1. Maximum DS3 packet forwarding rates are achieved only when the AT-AR048 is installed in a Rapier 24*i* whose serial number ends with the letter N or higher. If maximum DS3 performance is not required, the AT-AR048 can be installed in any Rapier 24*i* whose serial number ends in J, K, L, or M. The serial number can be found on the underside of the switch (see [Figure 1 on page 5](#)).

Figure 1: Serial number label, as found on underside of switch



## Operating Environment And Regulatory Standards

This section provides an overview of the recommended operating environment for NSMs, as well as regulatory and conformance standards. Detailed safety and conformance information can be found in the Safety and Statutory Information booklet for your switch or router.

### Environmental Conditions

- Operating temperature range: 0 °C to 40 °C (32 °F to 104 °F)
- Storage temperature range: -25 °C to 70 °C (-13 °F to 158 °F)
- Relative humidity range: 5 to 95% non-condensing

### Regulatory Standards

#### AT-AR040

- Listing: UL, cUL, TUV
- Safety: UL 60950-1, CAN/CSA-C22.2 No. 60950-1-03, EN60950-1, AS/NZS60950.1
- EMC: Radiated: EN55022 class A, FCC class A, VCCI class A, AS/NZS CISPR22 class A
- Immunity: EN55024

#### AT-AR041 and AT-AR042

- Listing: TUV
- Safety: EN60950-1, AS/NZS60950.1
- EMC: Radiated: EN55022 class A, AS/NZS CISPR22 class A
- Immunity: EN55024
- Network interface: TBR3, ACA TS031, iDA ISDN 1


#### AT-AR048

- Listing UL, cUL
- Safety: UL60950-1, CAN/CSA-C22.2 No. 60950-1-03
- EMC: Radiated: FCC Part 15 class A, IC-03 class A
- Network interface: ANSI T1.102, ANSI T1.404, ANSI T1.107, ANSI T1.231

## AT-AR040 NSM

The AT-AR040 provides four Port Interface Card (PIC) slots (Figure 2 on page 6).

Figure 2: AT-AR040 NSM with three PICs



This NSM supports combinations of the following PICs (with a maximum of two E1/T1/PRI cards):

- AT-AR020 PRI E1/T1 (Primary Rate ISDN)<sup>1</sup>
- AT-AR021 (S) BRI-S/T (Basic Rate ISDN S/T)
- AT-AR021 (U) BRI-U (Basic Rate ISDN U)
- AT-AR023 SYN (Synchronous RS-232/X21/V35 DCE/DTE to 2Mps)
- AT-AR024 ASYN4 (Four Asynchronous ports)
- AT-AR027 VoIP-FXS<sup>2</sup>

1. Up to two PRI E1/T1 PIC cards (AT-AR020) can be installed in the NSM. A maximum of 32 TDM slots are allowed in each NSM row, and the maximum aggregate bandwidth for each row is 2.6 Mbps. If two PRI E1/T1 PICs are installed, the first must be in the lower row (bay 0 or 1), and the second must be in the upper row (bay 2 or 3). If an AT-AR020 E1/T1 PRI PIC is installed in one of the rows in the NSM and operating in E1 mode, then this row cannot also have an AT-AR021(S) BRI-S/T PIC or an AT-AR021(U) BRI-U PIC installed.

2. When the AT-AR040 is installed in an AR740 router, a maximum of four AT-AR027 PICs can be installed in the router and NSM.

Please note that the AT-AR022 ETH PICs and AT-AR026 4ETH PICs are not recommended for use in the NSM PIC bays, as performance of these interfaces is likely to be reduced and packet loss may occur.

### Interface numbering for AT-AR040 NSMs

Interface numbering for each interface type (e.g., BRI, PRI, SYN, ETH, PORT) begins at 0 on the base switch or router and continues until all interfaces of that type on the base unit are numbered. For AR700 Series routers, the numbering then continues with the PIC interfaces installed directly in the router's PIC bays, starting at PIC bay 0. For switches and routers, the numbering then continues with the interfaces installed in the NSM, starting with NSM PIC bay 0, and ending with NSM PIC bay 3.

It is recommended that PICs be installed in the router's PIC bays and NSM's PIC bays in the above sequential order, so that interface numbering is not changed when a new PIC is installed.

## AT-AR041 and AT-AR042 NSMs

The AT-AR041 NSM provides eight Basic Rate ISDN S/T WAN ports ([Figure 3 on page 7](#)), while the AT-AR042 NSM provides four Basic Rate ISDN S/T WAN ports ([Figure 4 on page 7](#)). In both cases the ports use RJ-45 connectors and provide TE interfaces. There are two status LEDs per port ([Table 3 on page 14](#)).

AT-AR041 and AT-AR042 NSMs support point-to-point links. Point to multi-point links are not supported.

Figure 3: AT-AR041 NSM





Figure 4: AT-AR042 NSM




## Basic Rate ISDN Interfaces

AT-AR041 and AT-AR042 NSMs provide Basic Rate ISDN (BRI S/T) interfaces, which support two 64kbit/s channels and one 16kbit/s D channel.

Both BRI NSMs support only TE mode. The switch or router should be configured as a TE for normal operation.

Board-mounted jumpers determine the interface termination. By default, the jumpers are set in the Terminated position (bridging terminals 2 and 3) when NSMs leave the factory ([Figure 5 on page 8](#)). To set the line pairs to Not Terminated, remove the jumper and replace it so that it bridges terminals 1 and 2. If the building wiring provides the correct termination for an ISDN TE-to-NT circuit, the jumper should be set in the Not Terminated position.

Figure 5: Location of jumpers on BRI NSMs



**Caution** If the building wiring provides the correct termination for an ISDN TE-to-NT circuit, the jumper should be set in the Not Terminated position.

The *Integrated Services Digital Network (ISDN)* chapter of the Software Reference for your switch or router has additional information on termination of ISDN lines. If you are unsure whether to terminate the line or not, contact your ISDN service provider or your authorised Allied Telesis distributor or reseller.

The pinout of the BRI interface is shown in [Table 2](#).

Table 2: Pinout of the Basic Rate ISDN S/T interface


Pin	S/T Interface Functions
1	-
2	-
3	TX+
4	RX+
5	RX-
6	TX-
7	-
8	-



## ISDN S/T Interface Cables

Figure 6 on page 9 shows how to wire a cable to connect a Basic Rate Interface (BRI) to the ISDN network terminating equipment (NT).

Figure 6: Pin wiring diagram for an ISDN Basic Rate straight-through Interface cable




## Testing a BRI NSM

A Test Facility is built into all switch and router software. The Test Facility is designed to test physical interfaces. Testing can be performed while the switch or router is operational, but any interfaces being tested are dedicated to the Test Facility. The Test Facility can be thought of as a specialised interface module like PPP or Frame Relay.

When testing BRI interfaces, the Test Facility is used in conjunction with a BRI S/T loopback plug. A loopback plug must be inserted into each interface that you wish to test. Figure 7 on page 9 shows how to wire the loopback plug.

Figure 7: BRI S/T loopback plug



For more information on the Test Facility's operation, see the *Test Facility* chapter of the Software Reference for your switch or router.

To test a specific AT-AR041 or AT-AR042 interface, insert a BRI S/T loopback plug into the interface and enter the command:

```
enable test interface=brin
```

where  $n$  is the interface number.

To test all AT-AR041 or AT-AR042 interfaces at once, insert BRI S/T loopback plugs into all NSM BRI interfaces and enter the command:

```
enable test interface=expansion
```

In both cases the tests will run for 4 minutes.

Test results are displayed with the command:

```
show test
```

which produces a display like that shown in [Figure 8 on page 11](#).

The status of the tests for each interface will be shown in the right-most column of the output. For more information on the meanings of the other figures, see the *Test Facility* chapter of the Software Reference for your switch or router.

If you are unsure about running the Test Facility, or have difficulty evaluating the results, contact your authorised Allied Telesis distributor or reseller.

Figure 8: Example output from the **show test** command

Board	ID	Bay	Board Name	Rev	Serial number
Base	78		AR740	M1-15	46625812
PIC	38	0	AT-AR023-00 PIC Sync	M1-1	5918255
NSM	95		AT-AR041-00 NSM 8BRI	P1-3	46624968
Interface	State	Result	Type	Duration (minutes)	Details Data( %OK )
Control					
eth0	complete	good	trans	0	- - -
			TP	1	good(100.0) -
			ENDEC	1	good(100.0) -
			MAC	1	good(100.0) -
eth1	complete	good	trans	0	- - -
			TP	2	good(100.0) -
			ENDEC	0	- - -
			MAC	2	good(100.0) -
syn0	complete	* BAD	RS-232dte	1	good(100.0) BAD
			dce	1	good(100.0) BAD
			X.21 dte	1	good(100.0) BAD
			dce	1	good(100.0) BAD
			V.35 dte	1	good(100.0) BAD
			dce	1	good(100.0) BAD
asyn0	complete	check this screen	-	4	- - -
asyn1	complete	good	-	4	good(100.0) good
BRI0	complete	good	-	4	good(100.0) -
BRI1	complete	good	-	4	good(100.0) -
BRI2	complete	good	-	4	good(100.0) -
BRI3	complete	good	-	4	good(100.0) -
BRI4	complete	good	-	4	good(100.0) -
BRI5	complete	good	-	4	good(100.0) -
BRI6	complete	good	-	4	good(100.0) -
BRI7	complete	good	-	4	good(100.0) -

For more complete testing, connect the BRI interface to an external ISDN test device and use the **enable bri ctest** command and the **disable bri ctest** command from the *Integrated Services Digital Network (ISDN)* chapter (of the Software Reference for your switch or router). This test will execute conformance loopback tests and generate packets.


If a test fails, please contact your authorised Allied Telesis distributor or reseller.

## AT-AR048 NSM

The AR048 NSM provides a single unchannelised DS3 interface with two BNC connectors (transmit and receive). [Figure 9 on page 12](#) shows the NSM's front panel.

To achieve maximum performance the NSM should be installed in a Rapier 24*i* whose serial number ends in the letter N or higher. If installed in a Rapier 24*i* whose serial number ends in the letter J, K, L, or M, the NSM will still operate, but at a reduced rate. The NSM should not be installed in a switch whose serial number ends in the letter i or lower. The serial number is located on the switch's underside. For more information, including a sample serial number, see ["Compatible Base Units For NSMs" on page 4](#).

Figure 9: AT-AR048 NSM



### DS3 Interface

The AT-AR048 NSM provides one standards-based unchannelised DS3 interface. The interface has the following features:

- 44.736 Mbit/s interface rate, 44.210 Mbit/s payload data rate
- Separate transmit (Tx) and receive (Rx) BNC connectors
- 75-ohm impedance
- B3ZS line encoding
- Automatic compensation for lines up to 135m (450ft)
- Loop or internal timing
- C-bit framing
- Support for PPP and Frame Relay encapsulation

The interface meets the following specifications:

- ANSI T1.103, Digital Hierarchy - Synchronous DS3 Format
- ANSI T1.107, Digital Hierarchy - Formats
- ANSI T1.231, Digital Hierarchy - Layer 1 In-Service Digital
- RFC 2496 (DS3 MIB)

### DS3 Interface Cables

Use 75-ohm RG59 coaxial cables with BNC connectors. Two cables are required, one for transmit and one for receive. Neither cable should exceed 135m (455ft) in length.

## Testing a DS3 NSM

A Test Facility is built into all switch software. The Test Facility is designed to test physical interfaces. The interface is not available for network operations while the test is running.

For more information on the Test Facility's operation, see the *Test Facility* chapter of the Rapier Switch Software Reference.

To test an AR048 DS3 interface, connect a 75-ohm RG59 cable between the transmit and receive BNC connectors and enter:

```
enable test interface=ds3n
```

where *n* is the interface number.

Alternatively, enter the command:

```
enable test interface=expansion
```

In both cases the tests will run for 4 minutes.

Test results are displayed with the command:

```
show test
```

which produces a display like that shown in [Figure 10 on page 13](#). A more detailed output (with frame counts) can be displayed with the command:

```
show test interface counter
```

which is shown in [Figure 11 on page 13](#).

Figure 10: Example output from the **show test interface** command for a DS3 interface

Board	ID	Bay	Board Name	Rev	Serial number
Base	114		AT-RP24i Rapier 24i	M2-0	41376726
NSM DS3	187		AT-AR048 NSM DS3	M1-1	49986061

Interface	State	Result	Type	Duration (minutes)	Details Data ( %OK )	Control
DS30	complete	good	-	4	good (100.0)	

Figure 11: Example output from the **show test interface counter** command for a DS3 interface

Board	ID	Bay	Board Name	Rev	Serial number
Base	114		AT-RP24i Rapier 24i	M2-0	41376726
NSM DS3	187		AT-AR048 NSM DS3	M1-1	49986061

Interface	State	Type	Duration (minutes)	Tx	Frame Counters RxTotal	RxGood	RxBad
DS30	complete	-	4	001045030	001045030	001045030	000000000

For more information on the meanings of the output, see the *Test Facility* chapter of the Rapier Switch Software Reference. If you are unsure about running the Test Facility, have difficulty evaluating the results, or if a test fails, please contact your authorised Allied Telesis distributor or reseller.

## LEDs and What They Mean

This section provides information on LEDs for NSMs and related hardware.

### AT-AR040 NSM

The AT-AR040 NSM unit has no independent LEDs. See [Table 5 on page 15](#) for information about related LEDs found on the base-unit switch or router.

### AT-AR041 and AR042 NSMs

The AT-AR041 and AT-AR042 have two LEDs per port. The LEDs are located on the NSM's face-plate.

Table 3: AT-AR041 and AT-AR042 LEDs

LED	State	Function
Active	Green	Lit when the BRI has successfully completed the exchange of INFO 1 and INFO 2 signals, and INFO 3 and INFO 4 signals are present on the link. This means the ISDN interface is correctly connected to a working NT device.
	Off	There is no connection to the ISDN, or the ISDN has deactivated the connection.
Data	Amber	For on-demand ISDN, lit when there is a call up over the respective B channel.  For permanent circuits, lit when HDLC packets are being exchanged between the switch or router and another TE end system device (normally another switch or router) over the respective B (data) channel.
	Flashing Amber	For on-demand ISDN, flashing when data is being exchanged.
	Off	For on-demand ISDN, Off when there is no active connection or when continuous data exchange is occurring.  For permanent ISDN circuits, Off when no data exchange is occurring.

## AT-AR048 NSM

The AT-AR048 has the following LEDs on its face-plate.

Table 4: AT-AR048 LEDs

LED	State	Function
Active	Green	Lit when the Line Interface Unit (LIU) is receiving a signal.
Loop	Green	Lit when any loopback is active.
LOS	Amber	Lit when the received signal is lost. This usually indicates a network disruption, such as a cable being disconnected or a device failure.
LOF	Amber	Lit when the DS3 framer cannot extract valid frames from the received signal.
AIS	Amber	Lit when an Alarm Indication Signal is detected.
FERF	Amber	Lit when a Far End Receive Failure signal is detected. This indicates the far end is receiving an AIS, LOS, or LOF signal.

## Switch and Router LEDs Related to NSMs

Switches and routers with NSM bays have the following LEDs built into their chassis.

Table 5: Base-unit NSM LEDs (rear panel)

LED	State	Function
In use	Green	An NSM is installed, is receiving power, and is operational. The NSM and its PICs are not ready for hot swap.
	Off	No NSM is installed, or the NSM is not installed correctly (the switch or router has not recognised the NSM).
Swap	Green	The NSM and its PICs are ready to be hot swapped.
	Off	The Hot Swap button must be pressed before the NSM or its PICs can be hot swapped, or the software release does not support hot swapping. Hot swapping is supported by software version 2.3.1 or later.

## PIC LEDs

The following tables may be helpful when diagnosing possible AT-AR040 NSM operational faults. These LEDs are located on the face-plate of the respective PIC. PICs are expansion options and must be purchased separately.

Table 6: PIC LEDs (AT-AR020 PRI E1/T1)

LED	Function
D Data	[ISDN mode only] Lit when HDLC packets are being exchanged between the switch or router and the ISDN switch over the D (signalling) channel.
B Data	Lit when HDLC packets are being exchanged between the switch or router and another end system device (normally another switch or router) over any of the B (data) channels.
Active	Lit whenever operational (i.e., no RAI or AIS set) frames are being received on the respective interface (PRI 0 or PRI 1) from another source.
NT	[ISDN mode only] Lit when the PRI1 is operating in NT mode. This LED should not be lit during normal operation.

Table 7: PIC LEDs (AT-AR021(S) BRI-S/T)

LED	Function
B1, B2	For on-demand ISDN, lit when there is a call up over the respective B channel and flashing when data is being exchanged.  For permanent circuits, lit when HDLC packets are being exchanged between the switch or router and another TE end system device (normally another switch or router) over the respective B (data) channel.
Active	Lit when the BRI has successfully completed the exchange of INFO 1 and INFO 2 signals, and INFO 3 and INFO 4 signals are present on the link. This means that the ISDN interface is correctly connected to a working NT device.
D	Lit when HDLC packets are being exchanged between the switch or router and the ISDN switch over the D (signalling) channel.

Table 8: PIC LEDS (AT-AR021(U) BRI-U)

LED	Function
B1, B2	Lit when HDLC packets are being exchanged between the switch or router and another TE end system device (normally another switch or router) over the respective B (data) channel.  For ISDN, lit when there is a call up over the respective B channel and flashing when data is being exchanged.
Active	Lit when the U interface is in the <i>Activated</i> state (i.e., it is in a fully operational at layer 1).
D	Lit when HDLC packets are being exchanged between the switch or router and the ISDN switch over the D (signalling) channel.

Table 9: PIC LEDs (AT-AR023 SYN)

LED	Function
Tx	Lit when data is being transmitted over the synchronous interface.
Rx	Lit when data is being received on the synchronous interface.



Table 10: AT-AR026 4ETH PIC LED functions (Two LEDs per port)

LED	Function
Left	Lit when the port is operating at 100Mbps and full duplex.
Right	Lit when a link has been established. Flashing when data is being transmitted through the port.

Table 11: AT-AR027 VoIP-FXS PIC LED functions

LED	State	Function
Off Hook/Ring	Off	The port is on-hook.
	Green	The port is off-hook.
	Flashing	An incoming call is present on the port.
PIC Reg	Off	The PIC is not registered with a gatekeeper and external phone calls cannot be made.
	Flashing	The PIC is registered with a gatekeeper or gatekeeper has been set to "None". External calls can only be made if the PIC is registered with a gatekeeper.
PIC Error	Off	The PIC is okay.
	Green	An internal error has occurred. Reset the PIC using the <b>reset voip</b> command.

The AT-AR024 ASYN4 PIC does not have LEDs.

## Hot Swapping

Hot swapping is the installation or removal of a component (such as an NSM) without powering down or restarting the switch or router.

NSMs can be hot swapped in and out of switches and routers that are running Software Version 2.3.1 or later. To find out which software version your switch or router is running, use the command:

```
show install
```

See the *Network Service Module Installation and Safety Guide* for instructions on how to hot swap your NSM.

### Hot Swapping the AR040 NSM with PICs



**Caution** You cannot hot swap PICs. Before installing or removing a PIC from a PIC bay in a switch or router, you must disconnect all power sources to the switch or router. To install or remove a PIC from an AR040 NSM, you must first either physically remove the NSM from the switch or router (using the hot swap method), or disconnect all power sources to the switch or router.

You can hot swap the AT-AR040 NSM with PICs installed in its PIC bays. There is no need to remove the PICs before hot swapping the NSM.

When an AR040 NSM with PIC cards is hot swapped out, and an identical combination of AR040 and PICs is hot swapped into the same bay, the software configurations for the PIC interfaces are preserved across the hot swap. In this case, software modules configured to the PIC interfaces transfer to the newly swapped in interfaces.

When an AR040 NSM with PICs is hot swapped out and a different combination of AR040 and PICs is hot swapped into the same bay, new interface instances are created for any new PIC types or PIC types that are in different bays (the old interface instances are discarded). For any PIC in the combination that is replaced by a PIC of the same type, interface instances are preserved.

### Behaviour of Hot Swapped Interfaces

When an interface (NSM) is hot-swapped out, its interface instances become dormant. They stay dormant until either another interface of the same type is hot-swapped into the bay, in which case they are reactivated, or an interface of a different type is hot-swapped into the bay, in which case they are discarded.

Dormant interfaces are included in the **show interface** command output ([Figure 12 on page 19](#) and [Figure 13 on page 19](#)) and in the SNMP interfaces MIB, marked as swapped out. In other switch or router commands, however, the switch or router behaves as though dormant interfaces do not exist.

Instances of higher-level modules (such as LAPD and Q931, ISDNCC, PPP, and IP) do not become dormant when an interface becomes dormant. Instead they behave as if the interface has stopped communicating, for example, as if the cable has been unplugged.

The configuration script is not scanned for commands relating to hot-inserted interfaces until the switch or router is restarted. These interfaces must be configured manually.

The switch or router does not update the MAC address of any hot-swapped Ethernet interface until the switch or router is restarted.

All other commands that show or set interface properties behave as if swapped-out interfaces do not exist. Commands that operate on multiple interfaces skip swapped-out interfaces. Commands specified explicitly to a dormant interface display an error message.

Figure 12: Example output from the **show interface** command

```

Interfaces                                     sysUpTime:                00:00:46

DynamicLinkTraps.....Disabled
TrapLimit.....20

Number of unencrypted PPP/FR links.....0

ifIndex  Interface      ifAdminStatus ifOperStatus              ifLastChange
-----
  1      eth0           Up            Up                        00:00:03
  2      eth1           Up            Down                     00:00:00
  3      bri0           Up            Swapped out              00:00:43
  4      eth2           Up            Swapped out              00:00:42
-----

Interface name summary

Interface Full name
-----
asyn0      asyn0
asyn1      asyn1
eth0       eth0
eth1       eth1
-----

```

Figure 13: Example output from the **show interface** command for a specific interface

Interface..... bri0	
ifIndex.....	3
ifMTU.....	1712
ifSpeed.....	144000
ifAdminStatus.....	Up
ifOperStatus.....	Swapped out
ifLinkUpDownTrapEnable...	Disabled
TrapLimit.....	20
Interface Counters	
ifInOctets .....	52190
ifInUcastPkts .....	3070
ifInNUcastPkts .....	0
ifInDiscards .....	0
ifInErrors .....	0
ifOutOctets .....	52190
ifOutUcastPkts .....	3071
ifOutNUcastPkts .....	0
ifOutDiscards .....	0
ifOutErrors .....	0

## Troubleshooting

---

This section provides information on how to detect and resolve problems with NSMs.

Other sources of troubleshooting information are:

- The Installation and Safety Guide and Hardware Reference for your switch or router.
- [www.alliedtelesis.com/support/](http://www.alliedtelesis.com/support/) .

**Performing the following tasks will eliminate the most common faults.**

1. Check that the NSM is correctly installed. See the *Network Service Module Installation and Safety Guide* for a step by step guide to installing an NSM.
2. Make sure the power cord is securely connected to the switch or router and the power outlet.
3. Check that the power supply voltage to the switch or router is stable.
4. Check that the correct data cables are being used and that their connections are secure.
5. Make sure that other network devices are working properly.
6. Use the **show install** command to check that the latest software release is loaded. The Software Reference for your switch or router has more information about obtaining and installing the latest software release.
7. If the switch or router is malfunctioning, reboot it by pressing the recessed Reset button or entering the command **restart reboot**. Alternatively, power OFF and ON the switch or router by disconnecting and reconnecting the main power supply (including, if connected, the RPS power).

## For More Information

---

This Reference has been developed to familiarise you with the hardware features of Network Service Modules (NSMs). The Reference provides information that will assist you with the process of managing and servicing an NSM. For information about installing an NSM, see the *Network Service Module Installation and Safety Guide*.

### Document Sets

There are several sources of further information:

- The *Network Service Module Installation and Safety Guide*, which outlines the procedure for installing NSMs.
- The Hardware and Software References for your switch or router, which provide information on related hardware and software features.
- The *Port Interface Card Installation and Safety Guide*, which outlines the procedure for installing PICs; and the *Port Interface Card Hardware Reference*, which provides detailed information on PICs.

You can find these documents on the CD-ROM bundled with your switch or router, or at [www.alliedtelesis.co.uk/site/products/](http://www.alliedtelesis.co.uk/site/products/).

### Contacting Us

With locations covering all of the established markets in North America, Latin America and Europe, Allied Telesis provides localized sales and technical support worldwide. To find our representative nearest you, visit Allied Telesis on the web at [www.alliedtelesis.com](http://www.alliedtelesis.com).